

# **ECLIPSE**

LABORATORIES

October 26, 2006

P-6389

Mr. Lawrence Keim  
Innovatier  
2769 New Tampa Highway  
Lakeland, FL 33815

Dear Lawrence:

We performed the NCITS 322 Card Flexure test on your white test cards. The tests and results as described below:

### **NCITS 322 Card Flexure**

Four test cards were flexed up along the Axis A orientation. Four additional cards were flexed along the Axis B orientation at a rate of 60 cycles per minute until a total fracture of about 1/2 inch was observed or until 100,000 flex cycles is reached.

### RESULTS:

The flexure results are shown in the table below:

<u>Card type</u>	<u>Axis</u>	<u>Flex cycles until fracture</u>
white	A	100,000*
	B	100,000*

\* the test was stopped after 100,000 cycles without fracture.

Please call should you have questions or concerns.  
Thanks again for choosing Eclipse Laboratories testing services.



Kevin Tall  
Eclipse Laboratories, Inc.

Enclosure  
Test Cards