

ECLIPSE
LABORATORIES

November 27, 2006

P-6421A

Mr. Brandon Clark
Innovatier
2769 New Tampa Highway
Lakeland, FL 33815

Dear Brandon:

We performed the NCITS 322 Card Flexure test on your white test cards possessing red LEDs and activation switch. The tests and results as described below:

NCITS 322 Card Flexure

Six test cards were flexed up along the Axis A orientation (three face up, three face down). Six additional cards were flexed along the Axis B orientation at a rate of 60 cycles per minute until a total fracture of about 1/2 inch was observed or until 100,000 flex cycles is reached.

RESULTS:

The flexure results are shown in the table below:

<u>Card type</u>	<u>Axis</u>	<u>Flex cycles until fracture</u>
White side up	A	100,000*
Circuit side up	A	100,000*
White side up	B	100,000*
Circuit side up	B	100,000*


* the test was stopped after 100,000 cycles without fracture.

Comment:

The LEDs on all the cards illuminated after the 100,000 cycles.

Please call should you have questions or concerns.

Thanks again for the opportunity to be of service.


Kevin Tall
Eclipse Laboratories, Inc.

Enclosure
Test Cards